

Sub-Protocol: Metal Patterning via Lift-Off

Description: This document details the protocol for the high-resolution image reversal lithography used to produce the lift-off profile for metal patterning in the PIE Foundry standard microfabrication process. It is tailored for use on Parylene C coated silicon wafers.

MATERIALS

Acetone
Isopropanol (IPA)
N-Methylpyrrolidone (NMP)

EQUIPMENT

Glass dishes designated for lift-off
Sonicating bath

PROCESS

1. ACETONE SOAK

Note: Perform all steps in solvent fume hood

Note: Lift-off is a particulate generating process. Expect dishware and tweezers to become contaminated by metal particles. Designated tweezers and glassware for lift-off only processing.

- 1.1. Soak wafers overnight in room temperature acetone bath. Features should begin to appear after a few minutes. If not, the photoresist profile may be incorrect.
 - a. Bath will need to be covered in aluminum foil to prevent solvent evaporation overnight.
 - b. If possible, wafers should be stood vertical to reduce particle redeposition.

2. PREPARE SOLVENT BATHS

- 2.1. The following day prepare solvent baths in fume hood (organic solvents must be in glass containers marked for liftoff):
 - a. NMP solution in ultrasonic bath set to 60 °C
 - b. Room temperature bath of NMP rinse
 - c. Room temperature bath of IPA
 - d. Room temperature bath of DI water

3. DRY-BAKE

Note: this step should be performed immediately before photoresist deposition

- 3.1. Bake wafers at 60 °C in an oven under light vacuum (35-40 cmHg) and N₂ flow (15-20 sccm) for >15 minutes

4. ULTRASONIC BATH

- 4.1. Transfer wafer from acetone bath to NMP ultrasonic bath. As the wafer is removed from the solvent immediately spray with NMP while holding the wafer at a downward sloping angle to remove all remaining metal flakes. Make all efforts to prevent the wafer from drying.
- 4.2. Apply ultrasonic for 2 minutes

5. SOLVENT RINSE

- 5.1. Transfer wafer to the NMP rinse. Again, spray vigorously with NMP squeeze bottle while holding the wafer at a downward sloping angle to remove all remaining metal flakes. Let rinse for > 5 minutes.
- 5.2. Transfer wafer to the IPA rinse. Spray vigorously with NMP squeeze bottle while holding the wafer at a downward sloping angle to remove all remaining metal flakes. Let rinse for > 5 minutes.
- 5.3. Transfer wafer to the DI rinse. Spray vigorously with IPA squeeze bottle while holding the wafer at a downward sloping angle to remove all remaining metal flakes. Rinse with DI water 3× times.
- 5.4. Blow dry with N₂

6. INSPECT AND CLEAN

- 6.1. Inspect features under compound microscope.
- 6.2. Clean up chemicals and dishes
 - a. Dispose of NMP and IPA in solvent waste bottle
 - b. Glass dishes should be rinsed clean with acetone, IPA, and DI water